PLATINUM MODEL REMOTE CONTROL - WIRELESS



Flashlight 🗨

Mode

PLATINUM

Press and hold this button to illuminate the light on the back of the remote.

Press and hold to raise the head •

Press and hold to lower the head -

Press to recall memory of position #1 •

Under bed light option ON/OFF button •

Press to bring bed to FLAT position • Pressing any button on the remote will cancel this operation.

Press to recall memory of position #3

Press to increase intensity of head massage

Press to increase intensity of foot massage Press and hold to raise the foot

Press and hold to lower the foot

Press to recall memory of position #2

Setting Memory Positions

Adjust the bed to the desired position for head, foot, massage and wave mode. Press and release the "S" button and then press and release desired Memory Position button 1, 2 or 3 to save the position.

Press to decrease intensity of head massage

Continue pressing this button to turn head massage OFF

Press to decrease intensity of foot massage Continue pressing this button to turn foot massage OFF

• Press to switch the massage between different wave modes

PLATINUM MODEL REMOTE CONTROL - WIRELESS

Easy Rest. Adjustable sleep system

Should you need to order a replacement remote control for your bed, or, on the rare occasion that the remote control loses communication with the base unit, you will have to perform this simple operation to allow the remote to communicate with your base unit.

Matching your hand control to the bed

The bed must be in the FLAT position in order to program the remote to operate the base unit. If your bed is not in the flat position start with Step 1. If it is already in the <u>completely flat position</u> proceed to Step 2.

Step 1 - Returning the Bed to a Flat Position

Using a ballpoint pen, or other skinny blunt head item such as a paper clip, press and release the reset button. The motors will activate and lower the head and foot section one at a time to the flat position. The bed is in the completely flat position when the motors stop running.

Step 2 - Pairing the Remote Control to the Base

With the bed in the completely flat position, use a ballpoint pen, or other skinny blunt head item such as a paper clip, to **press and hold** the reset button on the motor.

While pushing the RESET button, press and release any button on the hand control and then release the RESET button on the motor. The hand control should now be able to operate the base unit.



If you have followed these directions and are still having difficulty you can reach our Customer Service Department at **1-800-523-5383** Monday - Friday from 9 am to 5 pm (East Coast Time).

